

rcd cad symbol Complete Guide

rcd cad symbol: A Complete Guide to Understanding and Using RCD CAD Symbols

In the realm of electrical engineering, safety, precision, and clarity are paramount. One essential component that embodies these principles is the Residual Current Device (RCD), often represented through standardized symbols in CAD drawings. The RCD CAD symbol plays a crucial role in designing, analyzing, and maintaining electrical systems. This comprehensive guide delves into what the RCD CAD symbol is, its significance, standard representations, and best practices for implementation in CAD software.

What Is an RCD and Its Significance in Electrical Systems?

Understanding RCDs (Residual Current Devices)

An RCD, also known as a Residual Current Breaker (RCB) or Residual Current Circuit Breaker (RCCB), is a safety device designed to disconnect a circuit whenever it detects leakage current to the ground. Its primary purpose is to prevent electric shocks and protect people from potential harm caused by faulty wiring or appliances.

Key functions of RCDs include:

- Detecting imbalance between live and neutral conductors
- Quickly disconnecting power to prevent electric shock
- Providing protection against electrical fires caused by leakage currents
- Ensuring compliance with electrical safety standards

The Importance of RCDs in Modern Electrical Installations

In residential, commercial, and industrial settings, RCDs are vital safety components. They act as a safeguard against accidental contact with live parts, especially in wet environments or where electrical faults are more likely. Properly integrating RCDs in electrical schematics ensures safety compliance and reduces risk.

Understanding the RCD CAD Symbol

What Is a CAD Symbol?

A CAD (Computer-Aided Design) symbol is a graphical representation of an electrical component used in schematic diagrams, circuit layouts, and technical drawings. These standardized symbols facilitate quick understanding, consistent documentation, and effective communication among engineers and electricians.

The RCD CAD Symbol: Purpose and Usage

The RCD CAD symbol visually indicates the presence of a residual current device within an electrical schematic. It provides essential information about the device's type, ratings, and connections, enabling engineers and technicians to analyze and troubleshoot systems accurately.

Standardized Representations of RCD in CAD Drawings

International Standards and Symbols

Electrical symbols are governed by standards like IEC (International Electrotechnical Commission) and ANSI (American National Standards Institute). These standards ensure uniformity across drawings, making them universally understandable.

Common standards include:

- IEC 60617: International standard for graphical symbols for diagrams
- BS 7671: UK wiring regulations that specify symbols
- IEEE standards for electrical schematics

Typical RCD CAD Symbols and Variations

While the core concept remains consistent, variations in the RCD symbol can exist depending on regional standards or specific software libraries. Here are common features:

- A rectangle or circle representing the device
- An internal arrow or switch symbol indicating tripping functionality
- Labels such as "RCD", "RCB", or "RCCB"
- Ratings and specifications (e.g., current, sensitivity)

Common RCD symbol components:

- A rectangle with a curved line or arc to denote residual current detection

- A trip indicator symbol
- Connection points for line (live) and neutral

Sample representations:

Symbol Type	Description
----- -----	
IEC Standard	A rectangle with a trip symbol, often labeled "RCD"
Simplified	A circle with a diagonal line and labels
Detailed	Includes ratings, connection points, and internal circuitry

How to Read and Interpret RCD CAD Symbols

Component Identification

Understanding the symbol enables users to identify the device in a schematic accurately. Look for key features:

- Labeling (e.g., "RCD", "Residual Current")
- Connection points
- Trip indicator symbols

Understanding Ratings and Specifications

Most CAD symbols include annotations such as:

- Rated residual operating current (I_n)
- Rated residual short-circuit capacity
- Operating voltage

These details are crucial for selecting appropriate RCDs for specific applications.

Interpreting the Circuit Connection

The symbol indicates where the RCD connects within the circuit:

- Line (Live) connection
- Neutral connection
- Earth/ground connection, if applicable

Incorporating RCD CAD Symbols into Electrical Design

Best Practices for Using RCD Symbols in CAD Software

- Use standardized symbols from recognized libraries
- Clearly label the device with ratings and identifiers
- Maintain consistent symbol size and style throughout the schematic
- Confirm connections align with actual wiring diagrams
- Include notes or annotations for clarity

Creating Custom RCD Symbols

In cases where specific RCDs are used, or standards vary, engineers can create custom symbols:

- Use CAD software's symbol editor
- Incorporate relevant ratings and details
- Ensure the symbol adheres to applicable standards

Integrating RCD Symbols into Larger Electrical Diagrams

- Place symbols logically within the circuit flow
- Group related devices for clarity
- Use connecting lines to denote wiring routes
- Cross-reference with specifications and documentation

Benefits of Using Accurate RCD CAD Symbols

- Improved Clarity: Clear visual representation reduces misunderstandings
- Enhanced Safety: Accurate schematics help ensure proper installation and maintenance
- Compliance: Meets regulatory standards and facilitates inspections
- Efficiency: Speeds up design, troubleshooting, and modification processes
- Documentation: Provides comprehensive records for future reference

Common Challenges and Solutions in Using RCD CAD Symbols

Inconsistent Symbols Across Drawings

Solution: Adopt a universal library of symbols compliant with IEC or regional standards.

Misinterpretation of Symbols

Solution: Include detailed annotations and legends explaining symbols.

Software Limitations

Solution: Customize symbols or upgrade CAD tools to support comprehensive electrical schematics.

Conclusion

The rcd cad symbol is an indispensable element in electrical schematic diagrams, serving as a visual shorthand for residual current devices that prioritize safety and compliance. Understanding its standard representations, how to interpret it, and best practices for integration into CAD drawings is essential for electrical engineers, designers, and technicians. Proper use of RCD symbols ensures clarity, safety, and efficiency in electrical system design and maintenance. By adhering to established standards and leveraging effective CAD practices, professionals can create precise, informative, and compliant electrical schematics that serve their projects well into the future.

Remember: Always consult regional electrical standards and guidelines when selecting or creating RCD symbols to ensure compliance and safety in your designs.

RCD CAD Symbol: An In-Depth Analysis for Electrical Design and Safety

Electrical safety and precise circuit documentation are fundamental aspects of professional electrical engineering, and at the heart of this process lies the RCD CAD symbol. Recognized widely in electrical drawings, circuit diagrams, and CAD (Computer-Aided Design) tools, this symbol plays a crucial role in illustrating residual current devices (RCDs), also known as residual current circuit breakers (RCCBs). Understanding its design, application, and significance is vital for engineers, electricians, and safety inspectors alike. This article provides an expert-level review of the RCD CAD symbol, exploring its features, standards, variations, and practical importance in electrical schematics.

Understanding the RCD and Its Role in Electrical Safety

Before delving into the symbol itself, it's essential to clarify what an RCD is and why it's integral to

electrical safety systems.

What is an RCD?

An RCD (Residual Current Device), also called RCCB or RCM (Residual Current Monitor), is a safety device designed to prevent electric shocks and reduce electrical fire risks. It monitors the current flowing through live and neutral conductors; if it detects an imbalance—typically caused by a leakage to ground—it trips the circuit, disconnecting power within milliseconds.

Key functions of an RCD include:

- Protecting people from electric shocks during accidental contact with live parts.
- Preventing electrical fires caused by ground faults or insulation failures.
- Enhancing overall safety in residential, commercial, and industrial installations.

Operational principle:

An RCD compares the current flowing into the protected circuit via the live wire with the current returning via the neutral wire. Under normal conditions, these currents are equal. If there's a discrepancy (usually ≥ 30 mA for personal protection), the device rapidly disconnects the circuit.

The Significance of the RCD CAD Symbol in Electrical Drawings

In electrical schematics, symbols serve as universal visual language, simplifying complex circuit representations. The RCD CAD symbol is a standardized graphic that embodies the device's function, ensuring clarity and consistency across drawings, documentation, and CAD projects.

Why Is a Standardized Symbol Important?

- **Clarity:** Clear symbols prevent misinterpretation during installation, maintenance, or inspection.
- **Consistency:** Uniform symbols across documents aid communication among engineers, electricians, and inspectors.
- **Efficiency:** Simplifies schematic interpretation, reducing errors and installation time.
- **Compliance:** Aligns with international standards such as IEC, IEEE, or national codes, ensuring legal and safety adherence.

Design and Features of the RCD CAD Symbol

The RCD CAD symbol's design adheres to international standards, typically IEC 60617 or IEEE

315, which specify graphical conventions for electrical symbols.

Basic Structure of the RCD Symbol

The symbol generally incorporates the following components:

- Rectangular or Square Outline: Represents the device enclosure.
- Test Button: Usually depicted as a small circle or rectangle inside the symbol, indicating the presence of a test function.
- Trip Indicator: An optional element, often shown as a small lamp or indicator symbol.
- Connection Lines: Lines indicating the incoming (line) and outgoing (load) conductors.

A typical RCD symbol in CAD includes a combination of these elements, with specific standard conventions:

- A rectangle with a ?T? or test button symbol inside.
- A trip indicator symbol, often represented as a small circle or triangle.
- Input and output lines labeled appropriately.

Variations and Standardized Forms

Different standards and CAD libraries may include variations to denote specific types or features of RCDs:

- Type of RCD:
 - Type AC: Detects alternating residual currents.
 - Type A: Detects AC and pulsating DC residual currents.
 - Type B: Detects AC, pulsating DC, and smooth DC residual currents.
- Sensitivity Ratings:
- Symbols may include annotations indicating trip current thresholds (e.g., 30 mA, 100 mA).
- Additional Features:
 - Remote trip capability.
 - Integration with other safety devices.

Example list of common RCD symbol features:

- Test button (standardized as a small circle with ?T?).

- Trip indicator lamp.
- Connection terminals.
- Earth connection representation.

Standards Governing the RCD CAD Symbol

The design and usage of the RCD symbol are dictated by international and regional standards to ensure uniformity.

IEC 60617 Standard

The IEC 60617 graphical symbols standard provides detailed specifications for electrical symbols, including those for RCDs. It stipulates:

- Symbol shape and size.
- Internal features (test button, trip indicator).
- Connection conventions.

Advantages of IEC standards:

- Global acceptance.
- Clear guidelines for CAD drafting.
- Compatibility across software and documentation.

IEEE and Regional Standards

In the United States, IEEE standards and regional codes such as NEC (National Electrical Code) may specify different or supplementary symbols. Always verify regional requirements.

Integrating the RCD CAD Symbol into Electrical Designs

In practical CAD environments, the RCD symbol is part of a library of standard components. Proper integration involves:

- Selecting the Correct Symbol: Based on device type, features, and standards.
- Labeling Clearly: Including trip current, rated voltage, and device type.
- Connecting Properly: Ensuring the symbol's connection lines reflect actual wiring.
- Annotating for Clarity: Adding notes or specifications for installation or testing procedures.

Best practices include:

- Using standardized symbols from recognized libraries.
- Keeping symbols consistent throughout the project.
- Incorporating test points and monitoring features as per design requirements.

Practical Implications of Using the RCD CAD Symbol

Accurate depiction of RCDs in schematics impacts multiple facets of electrical safety and project execution.

Design Accuracy and Safety Compliance

Proper symbol usage ensures that safety devices are correctly specified and installed, adhering to legal standards such as IEC 60364 or BS 7671 (UK wiring regulations).

Maintenance and Troubleshooting

Clear schematic symbols facilitate quick identification of RCDs during maintenance, enabling efficient testing, fault diagnosis, and replacement.

Training and Documentation

Standardized symbols serve as educational tools, helping new engineers and electricians understand circuit layouts and safety features.

Conclusion: The Value of the RCD CAD Symbol in Electrical Engineering

The RCD CAD symbol is more than just a graphical element; it embodies a crucial safety component embedded in modern electrical systems. Its precise design, adherence to standards, and thoughtful integration into schematics ensure that safety devices like residual current devices are correctly represented, installed, and maintained.

As electrical systems grow more complex and safety regulations tighter, understanding and correctly utilizing the RCD CAD symbol becomes indispensable for professionals committed to electrical safety, reliability, and clarity. Whether in residential wiring, industrial control panels, or complex automation systems, the symbol acts as a universal language bridging design intent with safety assurance.

In essence:

- Standardized symbols streamline communication.
- Accurate depiction enhances safety compliance.
- Clear schematics reduce installation errors.
- Knowledge of the symbol fosters better maintenance and troubleshooting.

Investing in understanding the RCD CAD symbol not only elevates professional competence but also contributes significantly to safer electrical environments worldwide.

Question What does the RCD CAD symbol represent in electrical drawings? The RCD CAD symbol represents a Residual Current Device (RCD) or Residual Current Circuit Breaker in electrical CAD drawings, indicating protection against earth faults and leakage currents. **How can I identify the RCD CAD symbol in a technical schematic?** The RCD CAD symbol typically appears as a switch or circuit breaker with a test button icon and may include labels like 'RCD' or specific current ratings. Refer to standard electrical symbol libraries in CAD software for accurate identification. **Why is it important to use the correct RCD CAD symbol in drawings?** Using the correct RCD CAD symbol ensures clarity in electrical schematics, facilitates proper device installation, and helps electricians and engineers understand protection requirements accurately. **Are there different RCD CAD symbols for various types of RCDs?** Yes, different RCD types such as RCBOs, RCCBs, and RCUs have distinct symbols in CAD standards, allowing for precise representation of their functions and ratings in electrical diagrams. **Can I customize RCD CAD symbols in my CAD software for specific projects?** Most CAD software allows customization or creation of user-defined symbols, including RCDs, to match project-specific standards or preferences, ensuring consistency across drawings. **Where can I find standard RCD CAD symbols for use in my electrical drawings?** Standard RCD CAD symbols can be found in electrical symbol libraries provided by CAD software vendors, industry standards like IEC or NEC, or through online repositories dedicated to electrical symbols.

Related keywords: rcd symbol, circuit diagram, electrical symbols, relay contact diagram, control circuit symbols, electrical schematic, rcd icon, residual current device symbol, electrical drawing symbols, device protection symbol

Rcd circuit symbol

RCD Circuit Symbol

An understanding of electrical symbols is essential for anyone working with electrical circuits, whether professionally or as a hobbyist. One of the most critical symbols in electrical safety and circuit design is the RCD circuit symbol. RCD, which stands for Residual Current Device, is a safety device designed to prevent electric shocks and protect wiring from damage caused by leakage currents. Recognizing the RCD circuit symbol is vital for reading electrical diagrams, ensuring proper installation, maintenance, and troubleshooting.

What is an RCD?

Before delving into the symbol itself, it's important to understand what an RCD does. A Residual Current Device detects imbalances between live and neutral conductors in an electrical circuit. If a leakage current exceeds a predetermined threshold—typically 30 milliamps—the RCD disconnects the circuit almost instantly, thus preventing potential electric shocks and reducing fire risks. RCDs are commonly used in residential, commercial, and industrial settings, especially in areas where electrical safety is paramount, such as bathrooms and outdoor installations.

Understanding the RCD Circuit Symbol

Basic Appearance of the RCD Circuit Symbol

The RCD circuit symbol is a standardized graphical representation used in electrical diagrams. It visually indicates the presence of an RCD device within a circuit. The symbol usually resembles a modified circuit breaker with specific markings to denote its residual current detection feature.

Typically, the symbol comprises:

- A rectangle or a box representing the device
- A toggle or switch symbol indicating the manual control
- An arrow or a special mark indicating residual current detection

In most schematic diagrams, the RCD symbol is simplified for clarity but adheres to international standards such as IEC 60417 or IEEE standards.

Common RCD Circuit Symbols

While variations exist depending on regional standards or diagram conventions, the most common RCD circuit symbols include:

- **Standard RCD symbol:** A rectangle with a curved or straight line indicating the device, often

with a test button symbol (a small circle or a 'T' inside)

- **RCD with test button:** The symbol includes a small circle or square labeled 'T' or 'Test' to denote the test button for checking device functionality
- **RCBO (Residual Current Breaker with Overcurrent):** A combination symbol indicating both residual current and overcurrent protection, often integrated with the RCD symbol

Standardized RCD Circuit Symbols According to International Standards

International standards help ensure consistency across electrical diagrams globally. The most widely recognized standards include IEC 60417 and IEEE standards, which provide detailed symbols for various electrical components, including RCDs.

IEC 60417 RCD Symbol

Under IEC 60417, the RCD symbol is identified as symbol number 5019. It generally features:

- A rectangle representing the device
- A switch symbol within the rectangle
- The designation 'R' or 'Residual' to emphasize its function

The symbol may also include a test button symbol, such as a small circle, to denote the manual testing feature.

IEEE Standard Symbols for RCDs

IEEE standards provide similar symbols, often with slight variations, emphasizing clarity and ease of understanding in complex diagrams.

How to Recognize the RCD Circuit Symbol in Diagrams

Being able to identify the RCD circuit symbol quickly is vital for circuit comprehension and troubleshooting. Here are some tips:

- Look for a rectangle or box with a switch symbol inside
- Check for the presence of a test button indicator (small circle or 'T')
- Notice the labeling, such as 'RCD,' 'RC,' or residual current markings
- Observe the connection points: RCDs are connected in series with the live and neutral conductors

Applications of the RCD Circuit Symbol in Electrical Diagrams

The RCD circuit symbol appears in various contexts, including:

- **Residential Wiring:** Protecting household circuits, especially in bathrooms, kitchens, and outdoor outlets
- **Commercial Installations:** Ensuring safety in office buildings and public spaces
- **Industrial Settings:** Protecting machinery and personnel from electrical faults
- **Generator and Panel Diagrams:** Indicating residual current protection in power distribution panels

Using this symbol correctly ensures that safety devices are properly documented and understood.

Designing Circuits with RCD Symbols

When designing electrical diagrams, proper placement and representation of RCDs are crucial. Considerations include:

- Positioning of the RCD in the circuit for optimal safety
- Marking the test button location
- Indicating the rated residual current (e.g., 30mA, 100mA)
- Including appropriate labels for clarity

Using standardized symbols guarantees that anyone reading the diagram can quickly identify the safety features incorporated.

Benefits of Recognizing and Using the RCD Circuit Symbol

Understanding the RCD circuit symbol offers several advantages:

- Facilitates accurate interpretation of electrical diagrams
- Ensures proper installation and maintenance of safety devices
- Helps in troubleshooting electrical faults efficiently
- Promotes compliance with safety standards and regulations
- Enhances communication among electricians, engineers, and inspectors

Conclusion

The **RCD circuit symbol** is a fundamental element in electrical schematics, representing the Residual Current Device crucial for electrical safety. Recognizing this symbol allows professionals and enthusiasts to interpret diagrams accurately, ensuring proper installation, operation, and safety compliance. Whether in residential, commercial, or industrial settings, understanding the standard symbols related to RCDs enhances safety measures and promotes best practices in electrical design and maintenance. Always refer to regional standards such as IEC 60417 or IEEE for precise symbol representations to maintain consistency and clarity in your electrical diagrams.

RCD Circuit Symbol: An In-Depth Exploration of Safety and Standardization

Introduction

RCD circuit symbol is a fundamental component in electrical diagrams, serving as a visual cue for a device that plays a crucial role in protecting individuals from electric shocks and preventing electrical fires. As electrical systems become increasingly complex and safety standards more stringent, understanding the significance and representation of RCDs (Residual Current Devices) in circuit diagrams is vital for engineers, electricians, and safety inspectors alike. This article delves into the intricacies of the RCD circuit symbol—its meaning, standardization, variations, and practical applications—offering a comprehensive guide for readers seeking to deepen their knowledge of electrical safety symbols.

Understanding the RCD and Its Importance

What is an RCD?

An RCD, or Residual Current Device, is a safety device designed to prevent fatal electric shocks and reduce the risk of electrical fires caused by leakage currents. It continuously monitors the current flowing through live and neutral wires; if it detects an imbalance—indicating a leakage to ground or a person—the device swiftly disconnects the power supply, typically within milliseconds.

Why is the RCD Critical?

- **Human Safety:** Protects individuals from severe electric shocks that can occur through faulty appliances, damaged wiring, or accidental contact.
- **Fire Prevention:** Detects leakage currents that could ignite flammable materials, preventing potential fires.
- **Regulatory Compliance:** Many electrical safety standards worldwide mandate the use of RCDs in residential, commercial, and industrial installations.

The Significance of Circuit Symbols in Electrical Diagrams

Standardization in Symbols

Circuit diagrams serve as universal languages for engineers and electricians. The clarity and consistency of symbols ensure that anyone reading the diagram can accurately interpret the components and their functions, regardless of language barriers or technical expertise.

Role of the RCD Circuit Symbol

The RCD circuit symbol visually communicates the presence of residual current protection within a system. It allows for quick identification during installation, inspection, troubleshooting, or maintenance, ensuring safety features are correctly implemented and functioning.

The RCD Circuit Symbol: Design and Variations

The Standard Symbol

The typical symbol for an RCD in electrical diagrams is a combination of standardized graphical elements, often adhering to international standards such as IEC (International Electrotechnical Commission) or BS (British Standards). Its core features include:

- A rectangle or a box representing the device.
- A test button symbol, often depicted as a small circle or a triangle within or near the rectangle.
- Connection lines indicating the live, neutral, and possibly earth connections.
- An internal arrow or line indicating the residual current detection mechanism.

Variations Across Standards

Different standards and regions may adopt slight variations in the symbol:

- IEC Standard: The symbol often includes a rectangle with a diagonal or a specific internal marking, sometimes accompanied by a test button symbol.
- British Standards (BS): The symbol may resemble a rectangle with a curved line or a specific "RCD" notation.
- ANSI/NEC (North American): The symbol may differ, often represented by a circle with an "R" or "RC" notation or specific device symbols.

Key Elements of the RCD Symbol

- Detection Mechanism Indicator: A small internal arrow or symbol indicating residual current detection.
- Test Button: Often represented as a small circle or a "T" within the device symbol, emphasizing the presence of a test function.
- Connection Lines: Show how the device is wired within the circuit, including live, neutral, and ground connections.

Interpreting the RCD Circuit Symbol in Practice

Reading Circuit Diagrams

When electricians or engineers encounter the RCD symbol within schematics:

- They recognize the device's location within the electrical system.
- Understand its purpose?residual current protection.
- Identify the connections for proper installation or troubleshooting.

Practical Implications

- Ensuring that the symbol correctly indicates the device's type and function.
- Verifying that the symbol matches the actual installed device.
- Checking for additional features like test buttons, surge protection, or combination devices.

Practical Applications and Safety Considerations

Installation Guidelines

- RCDs should be installed in appropriate circuits, especially in areas with increased risk like bathrooms, kitchens, and outdoor outlets.
- Proper wiring according to the symbol ensures correct operation and safety.

Testing and Maintenance

- The test button symbol indicates the device's test function.
- Regular testing (using the button) verifies the device's operation.
- Visual inspection of the symbol in diagrams helps in scheduled maintenance routines.

Troubleshooting Using Symbols

- Recognizing the RCD symbol aids in quick diagnosis.
- If an RCD trips frequently, the symbol helps identify its location within the circuit for inspection.

Standards and Future Trends

International Standards

Organizations like IEC, BS, and NEC have established guidelines for the RCD symbol to maintain consistency globally. Adhering to these standards ensures safety and interoperability across regions.

Emerging Technologies

- Smart RCDs: Integration with home automation systems may introduce new symbols or annotations.
- Digital Schematics: As electrical diagrams become more digital, symbols may evolve but retain core recognizable features.

Conclusion

RCD circuit symbol serves as a vital visual cue within electrical diagrams, encapsulating complex safety functions into a standardized graphical form. Its clear understanding enables professionals to design, install, inspect, and maintain electrical systems that prioritize safety and compliance. As electrical systems continue to advance, the importance of consistent, clear, and universally recognized symbols like the RCD continues to grow, safeguarding lives and property worldwide. Whether you're an aspiring electrician, a seasoned engineer, or a safety inspector, mastering the RCD circuit symbol is an essential step toward ensuring electrical safety in every project.

Question What does the RCD circuit symbol represent in electrical diagrams? The RCD circuit symbol represents a Residual Current Device, which is a safety device designed to prevent electric shocks and protect against earth faults by disconnecting the circuit when imbalance is detected. **Answer** How can I identify the RCD symbol in a circuit diagram? The RCD symbol typically looks like a rectangle with a test button inside, often marked with 'T' or a circle with a line through it, and may include labels such as 'RCD' or 'RCBO' to indicate its function. Why is understanding the RCD circuit symbol important for electrical safety? Knowing the RCD symbol helps electricians and engineers quickly identify safety devices in a circuit, ensuring proper installation, maintenance, and troubleshooting to prevent electric shocks and fire hazards. Are there different variations of the RCD

circuit symbol used in different standards? Yes, different electrical standards and regions may use slight variations of the RCD symbol, but the core design—a rectangle with a test button or a specific marking—remains consistent for easy recognition. Can the RCD circuit symbol be used to identify different types of residual current devices? While the basic symbol indicates an RCD, specific symbols or annotations may differentiate types such as RCBOs (Residual Current Breaker with Overcurrent protection) or RCCBs (Residual Current Circuit Breakers), depending on the diagram standards.

Related keywords: residual current device symbol, RCD symbol, RCD diagram, residual current circuit symbol, RCD icon, residual current device diagram, electrical safety symbol, RCD representation, residual current protection symbol, circuit breaker symbol

Read the full article online: [rca circuit symbol](#)